


DV-36

Quickstart Guide



Congratulations on the purchase of your DV-36! To start using your DV-36, simply follow these steps:

1. Connect your A/V cable to the 3 RCA jacks on your display. The other end connects to the "A/V OUT" jack on the DV-36.
2. (Optional) Connect the DV-36K keypad controller to the "KEYPAD" jack on the DV-36.
3. Insert a Certified Smart Media Card with A/V clips recorded with gold plated pad facing down and the end with the cut corner first into the DV-36.
4. Plug the power adapter's cord into the "DC IN" jack on the DV-36, and plug the other end into an electrical outlet.

For detailed manual instructions, see *DV-36 User's Guide*.

